
BLOCK DIAGRAM



TRIG MIX

The rhythm played by the legno cv is the sum of the two trig IN1 and IN2.

The trig mix pot. adjust the mix between the two trig input,

great for create poly rhythms.

If only IN1 or IN2 are plug the trig mix pot. adjust the level of the trig in.

FREQUENCY-

Adjusts the pitch of the sound of the legno cv also affects the resonance. You can control the freq.pot.with CV IN F and adjust the amount with CV AMT pot.

RESONANCE

Adjusts the resonance, ie the damping time of the legno cv Beyond a certain level the legno cv go into permanent oscillation. The level at which the oscillation begins varies with frequency. You can control the reso. pot.with CV IN R and adjust the amount with CV AMT pot.


DISTORTION

Adjusts the level of signal distortion of legno cv

The legno cv is an electronic euro rack module for create percussion sound and special efx,

OUT

created by LEP laboratories, the legno cv module take inspiration from the cassa of leploop synth.



DESIGN TONYLIGH

LEP L'ABORATORIES
TONYLIGHT & PEPPOLASAGNA

ARTWORK


RUGGGE.com

LEGNOCV



The legno cv is an electronic euro rack module for create percussion sound and special efx,

created by LEP laboratories, the legno cv module take inspiration from the cassa of leploop synth.



DESIGN

LEP L'ABORATORIES
TONYLIGHT & PEPPOLASAGNA

ARTWORK

RUGGGE.com

LEGNOCV



BLOCK DIAGRAM

TRIG MIX

The rhythm played by the legno cv is the sum of the two trig IN1 and IN2.

The trig mix pot. adjust the mix between the two trig input,

great for create poly rhythms.

If only IN1 or IN2 are plug the trig mix pot. adjust the level of the trig in.

FREQUENCY-


Adjusts the pitch of the sound of the legno cv also affects the resonance. You can control the freq.pot.with CV IN F and adjust the amount with CV AMT pot.

RESONANCE

Adjusts the resonance, ie the damping time of the legno cv Beyond a certain level the legno cv go into permanent oscillation. The level at which the oscillation begins varies with frequency. You can control the reso. pot.with CV IN R and adjust the amount with CV AMT pot.

DISTORTION

Adjusts the level of signal distortion of legno cv



OUT